THE CREATIVITY CONTINUES…

4304F2 Low Hourglass Fountain, 2 pc.



Rubber Stopper (19-47H)

Push rubber stopper to seal cord



Adapter (15-246H)

Adapter will be attach to 4304H and end of tubing will connect to adapter



Part list: CK408

QTY	Description	Henri Part #
1	Fact Book	60-01H
1	PS3 PUMP	24-63H
1	Adapter 1/2"MNPT X 1/2"Barb	15-45H
1	Adapter 1"MNPT X 1/2"Barb	15-246H
2	SHIM, PLASTIC BREAKOFF	01-58H
1	NKTubing 1/2" X 12"	04-34H

QTY	Description	Henri Part #
1	Rubber Stopper UK 1 HOLE	19-47H
1	RESTRICTOR R1	20-06H
1	HT WARRANTY CARD	60-03H
1	HT COMPANION SELL SHEET	60-04H
1	HT BAG 2MIL ZIPx6.25"x9.25" PRIN P	12-31H

Please note: Always follow local electrical codes and use 110V GFCI protected outlet.

Nota: Siempre siga los códigos électricos locales y utilizar un GFCI 110V protegida toma de corriente.

Remarque: Suivez toujours les codes électriques locaux et une utilisation 110V GFCI protégées prise de courant

• Fack Book - Livret d'informations - Manual de Información

IMPORTANT, this booklet contains maintenance, troubleshooting and winter care instructions.

IMPORTANTE, este folleto contiene instrucciones para el manteninmiento, resolución de problemas e instrucciones para el cuidado invernal.

IMPORTANT, cette brochure contient de maintenance, de dépannage et d'entretien d'hiver.